

# SNO CONE MACHINE

## OPERATION INSTRUCTIONS

Please carefully read this important information before use:

- Do not apply pressure onto handle until motor is fully up to speed.
- Do not let any metal get down in the chamber, or you will ruin the blades.
- Be careful to keep hands, hair, clothing and any other loose articles clear of the loading chamber and moving parts during operation.



1. Place the Water Catching Tray on a secure surface (i.e. Table), so that the spout and hose can run into the bucket below.
2. Place the Sno Cone Machine onto the tray.
3. Ensure the Ice Plunger moves freely from the UP position to the DOWN position.
4. Place ice into the loading chamber so that the plunger can rest on the ice inside of the chamber (ice should not be overflowing from the chamber).
5. Connect the Machine to a 110v power source.
6. When ready, grasp the plunger handle with one hand using slight pressure to keep the ice from coming back up and out of the loading chamber. With other hand, push in and hold the Motor ON button to engage the ice shredder. Once ice is shredded, release the motor button to turn OFF.
7. To shred more ice, carefully place additional ice in the loading chamber and safely repeat the above procedure.