

10'X10' POP-UP TENT

QUICK SET UP

Please carefully read this important information before use:

- Once tent is set up, always ensure to weigh down tent with sand bags provided.
- In extreme weather conditions such as high winds and heavy rain, please take down tent immediately to avoid damage.
- Do not leave tent unattended. Tent is designed as a temporary shelter. We do not recommend leaving it up for extended periods of time.

SET UP

1. **Open up shelter:**
Grasp the frame on opposite or shortest sides. Lift frame up slightly and pull backwards until shelter is fully opened.
2. **Secure Auto Slider:**
Secure the Auto Slider at each leg. The pins will auto-engage.
3. **Extend & secure shelter legs:**
Lift two adjacent outer legs. Slide the lower/inner legs out. Repeat on the remaining legs.
4. **Weigh down legs with sand bags.**

TAKE DOWN

1. **Collapse shelter legs:**
With a partner, slightly lift two corner legs. Depress toggle button and slide lower/inner legs into upper/outer legs. Repeat on remaining legs.
2. **Release Auto Slider:**
Release Auto Slider at each leg, push up on the truss near the slider. Release the pin by pulling the ring. Repeat on remaining legs.
3. **Close & store:**
Grasp the frame on the opposite or shortest sides. Lift the shelter up slightly and shake it while stepping towards your partner. Push the frame together until it is fully closed.
4. **Store the shelter in the cover bag.**



CAUTION: Be careful not to pinch fingers!



CAUTION: Do not use in extreme weather conditions!



CAUTION: Do not leave unattended!

